PROJECT NAME : MultiMoist CLR™



FORMULA NAME: Hydra Balance Hand Cream Bar

TRIAL CODE: 385.026.02A

Lab Formula INCI Supplier

Phase	Material Name	Mixed INCI	Supplier	% Material
Α	KahlJelly 7235 MB Natural	Ricinus Communis (Castor) Seed Oil Cera Alba (Beeswax) Copernicia Cerifera (Carnauba) Wax Ascorbyl Palmitate Tocopherol Helianthus Annuus (Sunflower) Seed Oil	KahlWax	42.50
A	KahlComplex 6422 Veggiesoft	Rhus Verniciflua Peel Wax Simmondsia Chinensis (Jojoba) Seed Oil Cetearyl Alcohol Myristyl Alcohol Caprylic/Capric Triglyceride Copernicia Cerifera (Carnauba) Wax Tocopherol Helianthus Annuus (Sunflower) Seed Oil	KahlWax	20.00
A	KahlWax 6607H Hydrolyzed Sunflower	Hydrolyzed Sunflower Seed Wax	KahlWax	5.00
A	KahlWax 2225 Phyto	Helianthus Annuus (Sunflower) Seed Wax Olea Europaea (Olive) Oil Unsaponifiables Rhus Verniciflua Peel Wax Shorea Robusta Resin	KahlWax	10.00
A	Eutanol G	Octyldodecanol	BASF	18.00
Α	Dehymuls PGPH	Polyglyceryl-2 Dipolyhydroxystearate	BASF	1.00
Α	MultiMoist CLR™	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
В	Perfume Sunny Apricot Natura ECO	Fragrance	Duellberg	0.50
				100.00

Operating instructions

Operating Instructions

Heat up A to 90°C and homogenize for a short moment. Add B and cool to 80°C while stirring. Fill into suitable packaging.

Directions for use:

Rub the bar once or twice between your hands or massage it directly on your hands. Bodytemperature will soften it and cream will be absorbed.

They are, to the best of our belief, correct, but are offered without obligation.