



Stay Cool 3 in1 Scalp Serum OW  
I-4.135.02A

<b>Phase</b>	<b>Material Name</b>	<b>US INCI</b>	<b>Supplier</b>	<b>% Material</b>
A	Deionized Water	Water	N.A.	72.64
A	Sepilife NUDE	Sodium Acrylate/Sodium Acryloyldimethyl Taurate Copolymer C15-19 Alkane Polyglyceryl-6 Laurate Polyglycerin-6	SEPPIC	3.00
B	Ethanol (96%)	Alcohol	Berkel AHK	15.00
B	<b>CutiBiome CLR™</b>	Octyldodecanol Leptospermum Scoparium Branch/Leaf Oil Piper Nigrum Seed Extract Magnolia Officinalis Bark Extract	CLR	3.00
C	<b>MultiMoist CLR™</b>	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
C	<b>AnnonaSense CLR™</b>	Annona Cherimola Fruit Extract	CLR	3.00
C	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.11
D	Perfume Meridian SPA WS	Fragrance	Frey+Lau	0.25
				<b>100.00</b>

#### **Operating Instructions**

Mix A and stir until homogeneous. Premix B and add it to A with stirring. Add C in this order. Adjust pH value to 6 and D as desired.

Direction for use:

For Scalp care: Take 5 drops and gently massage into the skin

For After Shave products: Apply to face after shaving

As serum: Apply to face and gently massage into the skin. Continue with your daily skin care routine.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)