



After Sun Spray  
II-5.311.02\_3

<b>Phase</b>	<b>Material Name</b>	<b>US INCI</b>	<b>Supplier</b>	<b>% Material</b>
A	Deionized Water	Water	N.A.	80.69
A	Zemea	Propanediol	DuPont Tate & Lyle	5.00
A	Keltrol CG-BT	Xanthan Gum	CP Kelco	0.20
A	Hydrolite-5	Pentylene Glycol	Cosnaderm	5.00
B	<b>SyriCalm™ CLR (PC)</b>	Water Phragmites Communis Extract Poria Cocos Extract	CLR	3.00
B	<b>DayMoist CLR™</b>	Water Hydrolyzed Corn Starch Beta Vulgaris (Beet) Root Extract	CLR	1.00
C	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.11
D	<b>Lactokine™ Fluid PF</b>	Milk Protein	CLR	5.00
				<b>100.00</b>

#### **Operating Instructions**

Mix A and stir until uniform. Add B under stirring. Adjust pH to 6-6.5 with C. Add D and stir until uniform.

Directions for use:

Apply the spray and gently massage into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)